

Smoothie King Water Filtration



A. Inlet Pressure Regulator/Gauge

B. Inlet Water Shutoff

C. Remote Faucet (not shown)

D. Water Inlet

E. Pre-Filter Housing

F. Outlet Pressure Gauge

G. Ice Machine Shutoff

H. Outlet to Ice Machine

I. Remote Faucet Shutoff

J. Outlet to Faucet

K. Post-Filter Housing



1 (800) 957-1975

How to change the pre-filter (clear housing)

1. Turn ice machine off
2. Close ice machine shutoff (G)
3. Close inlet water shutoff (B)
4. Open remote faucet by turning on
5. Place a pan or bucket under pre-filter housing (E)
6. Remove clear pre-filter sump (E)
*Use supplied plastic wrench and turn right to left.
Don't lose gasket.*
7. Remove and discard pre-filter
8. Clean pre-filter housing (E) with a clean cloth
9. Install a new pre-filter
10. Re-install clear pre-filter sump (E) with gasket by turning clockwise by hand.
*Finish tightening with supplied plastic wrench.
Do not over tighten.*
11. Open inlet water shutoff (B)
12. Allow water to run through faucet until air is purged from line (~4 minutes)
13. Close remote faucet
14. Check for leaks and tighten sump if necessary
15. Open ice machine shutoff (G)
16. Turn ice machine on

How to change the solid block filter (blue housing)

1. Turn ice machine off
2. Close ice machine shutoff (G)
3. Close inlet water shutoff (B)
4. Open remote faucet by turning on
5. Place a pan or bucket under solid blue block housing (K)
6. Remove blue sump (K)
*Use supplied plastic wrench and turn right to left.
Don't lose gasket.*
7. Remove and discard solid block filter
8. Clean blue housing (K) with a clean cloth
9. Install a new solid block filter
10. Re-install blue solid block sump (K) with gasket by turning clockwise by hand.
*Finish tightening with supplied plastic wrench.
Do not over tighten.*
11. Open inlet water shutoff (B)
12. Allow water to run through faucet until air is purged from line (~4 minutes)
13. Close remote faucet
14. Check for leaks and tighten sump if necessary
15. Open ice machine shutoff (G)
16. Turn ice machine on